



"PARTS LIST"





(FOR GRAVITY TYPE)
0.45 PL(Std.)
AL(Opt.)



▲ Repair kit includes:
No. 3, 5C, 9, 18, 19, 20B, 20D

▲ If necessary, please change the whole set of Maintenance Assembly (Air Cap, Nozzle, Needle) Individual part changes are not recommended.

No.	Description	Qty
1	Air Cap Set	1
2	Fluid Nozzle	1
3	Needle Valve Packing	1
4	Needle Valve Packing Seat	1
5	Spreader Adjusting Valve Set	1
	5A Spreader Adjusting Knob	2
	5B Housing	2
	5C O Ring	1
	5D Brass Washer	2
	5E Spring	1
	5F Stem	2
7	Needle Valve Guide	1
8	Fluid Adjusting Screw	1
9	Needle Valve Spring	1
10	Fluid Needle Set	1
11	O Ring	1
12	Gun Body	1
13	Air Hose Joint	1



- 1 Material Tube Assembly
 - 2 Yoke Assembly
 - 3 Lever
 - 4 Baffle (S-335)
 - 5 Cup Top Assembly
 - 6 Nut
 - 7 Cup Gasket
 - 8 Cup
- * Consumable parts; clean it only, NEVER soak it in solvent for a long time.

No.	Description	Qty	No.	Description	Qty
14	Air Adjusting Valve Set	1	20	Air Valve Seat Set	1
	14E Spring	1	20A	Air Valve Packing Seat	1
	14F Stem	1	20B	Air Valve Packing	1
15	Trigger Stopper	1	20C	Valve Body	1
16	Trigger Bearing Stud	1	20D	O Ring	1
17	Trigger	1	21	Fluid Joint	1
18	Air Valve Spring	1	22	Quick Coupler (Male)	1
19	Air Valve	1			

■ AIR FILTRATION SYSTEMS

■ ACCESSORIES



- Filter-regulator-in-1
- Removes dust, water and oil
- 99.9% absorption rate, 5 μm filter size
- Cleaner air, longer tool life

S806



S-081A



S-081B



S-081C



S-031



S-092



REPAIR KIT



2QT-B




2QT-S



10L-tank



S-AP HOSE



S-091A



S-091B